

TECHNOLOGY REFERENCE GUIDE



www.owners.honda.com

2012 Honda Civic Sedan EX, EX-L, Si, and GX
Technology Reference Guide

©2011 American Honda Motor Co., Inc. — All Rights Reserved

Printed in U.S.A.

31TR3C00
00X31-TR3-C000




2012 CIVIC SEDAN EX, EX-L, Si, and GX

TECHNOLOGY REFERENCE GUIDE

The Technology Reference Guide is designed to help you get acquainted with your new Honda and provide basic instructions on some of its technology and convenience features. This guide covers the Civic Sedan EX, EX-L, Si and GX trim levels.

This guide is not intended as a substitute for the Owner's Manual. For complete information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual.

Civic Sedan EX shown throughout guide



Auto Door Locks	2
Instrument Panel Indicators	4
Econ Button/Ambient Meter	6
Tire Pressure Monitoring System (TPMS)	7
Multi-Information Display (MID)	8
Bluetooth® HandsFreeLink® (HFL)	10

iPod® or USB Flash Drive	14
Bluetooth® Audio	15
Owner Link	16
Safety Reminder	17
Fuel Recommendation	17

AUTO DOOR LOCKS

Default Lock Setting



The doors are preset to lock when your vehicle reaches about 10 mph.

Default Unlock Setting



Only the driver's door is preset to unlock when you:

- **Shift** into Park (P) for automatic transmission vehicles.
- **Turn** the ignition switch to LOCK (0) for manual transmission vehicles.

Program how and when the vehicle doors automatically lock and unlock.

Programming the Auto Door Unlock Setting

Press the (+/-) buttons on the steering wheel to scroll through the menu options. **Press** SOURCE to select an option. See [page 9](#) for more information on the multi-information display and its controls.

1. Press MENU.




2. Select Customize Settings.



3. Select Door Setup.



4. Select Auto Door Unlock.



5. Select All Doors with Shift to P.



6. Press MENU to exit.



Programmable Auto Door Lock/Unlock Settings

Below are the options you can choose. See *Auto Door Locking/Unlocking* in your owner's manual for instructions on programming these settings.

AUTO DOOR LOCK			AUTO DOOR UNLOCK		
Auto Lock		When you reach 10 mph	Auto Unlock (all doors)		When you turn the ignition OFF
		When you shift out of Park			When you shift into Park
Turn off Auto Lock		Operate manually	Auto Unlock (only driver's door)		When you turn the ignition OFF
					When you shift into Park
Turn off Auto Unlock		Operate manually	Turn off Auto Unlock		Operate manually

INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information.



Malfunction Indicators

If an indicator remains on, there may be a problem; see your dealer

Charging system	ABS (anti-lock brake system)
Low brake fluid, Brake system	EPS (electric power steering)
Low oil pressure	Malfunction indicator lamp (check engine light)
SRS (supplemental restraint system)	VSA® (vehicle stability assist)
Transmission (blinking) (automatic transmission)	Low temperature

Condition Indicators

Action is needed by driver

Parking brake on: Release	Seat belt reminder: Fasten seat belt(s)
Door/Trunk open: Close door(s) / trunk	Maintenance Minder™: Make dealer appointment

Low fuel: Refill	Message indicator: See MID
Low tire pressure: Add air	High temperature: Drive slowly or pull over

On/Off Indicators

PASSENGER AIRBAG OFF (next to multi-information display)	Immobilizer Flashes: improperly coded key; use correct key
SIDE AIRBAG OFF	1st detent: parking lights on 2nd detent: headlights on
VSA OFF	Turn signals/hazards on
CRUISE CONTROL on	Fog lights on
CRUISE MAIN on	High beams on
ECON on *	

* not on Si trim

ECON BUTTON*

When turned on, the vehicle's engine performance, transmission, and air conditioning system are adjusted for maximum fuel economy.


Turning the ECON Mode On/Off

Helps you further maximize your fuel economy by modifying some vehicle functions.


1. Press **ECON**.



2. The **ECON** mode indicator comes on.



3. Check the multi-information display for the system status.



4. Press **ECON** again to turn the system off.

AMBIENT METER*

Indicates instant fuel efficiency using color-coded bars.

Ambient Meter Color-Coded Bars



* not on Si trim

TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

How It Works



Each tire valve stem contains a TPMS sensor.



When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on.



If a message also appears on the multi-information display, there may be a problem with the system. See your dealer.


What to Do

1. Visually inspect the tires for damage.

2. Use a tire air pressure gauge to check which tire(s) have low pressure.



3. Inflate the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.




MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.

Accessing the MID




Press the INFO button to change main displays.




Sub-displays



Press the SEL/RESET button to change sub-displays.



Main Displays




Steering Wheel Controls



(+) Button:
Press to scroll upward.

(◀) Button:
Press to go back to the previous display.

(-) Button:
Press to scroll downward.



Display/Information Button:
Change main displays.

SOURCE Button:
Press to enter your selection.

(▶) Button:
Press to go to the next display.


MENU Button:
Press to go to "Vehicle Menu" for customization and other settings.

BLUETOOTH® HANDSFREELINK® (HFL)

Place and receive phone calls through your vehicle's audio system. Visit handsfreelink.honda.com to check if your phone is compatible.

To prevent driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving.



How to Use HFL



Pick-Up button: Answer an incoming call, or go directly to the Phone screen.

Hang-Up/Back button: End a call, decline an incoming call, or cancel a selection.

Talk button: Make a call using a stored voice tag.



Use these two buttons to navigate through the HFL menus.

Audio selector knob: Rotate to scroll through selections and press to make a selection.




Back button: Press to cancel an operation or return to the previous screen.


Pairing Your Phone

Use the audio selector knob to make and enter selections.

1. Press the Pick-Up button to access the Phone screen. A prompt appears. **Select Yes.**



2. Make sure your phone is in discovery mode. **Select OK.**




3. HFL searches for your phone. **Select it when it appears on the screen. Go to step 4.**




If your phone does not appear:

Select Phone Not Found, and search for a HandsFreeLink device from your phone. Connect to HFL. Go to step 4.



4. HFL gives you a four-digit code. **Enter it on your phone when prompted. Select OK to complete.**





NOTE: To pair another phone to HFL (or if the prompts do not appear), you must use the Phone Setup menu. See your Owner's Manual for pairing instructions.


Making a Call

Use the audio selector knob to make and enter selections.


1. **Press** the Pick-Up button to go to the Phone screen.
3. **Enter** the phone number. **Select** the green Dial icon or **press** the Pick-Up button to call.



2. **Select** Dial.




4. The call is connected and heard through the vehicle speakers.



Receiving a Call

1. A notification is heard and the incoming phone number appears on the multi-information display.
3. **Press** the Hang-Up button to end or decline the call.



2. **Press** the Pick-Up button to accept the call.




Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system.

Use the audio selector knob to make and enter selections.


1. **Press** the Pick-Up button to go to the Phone screen.
3. **Scroll** through the list to find the name and number you want to call, and **select** it.



2. **Select** Phonebook.



4. The call is connected and heard through the vehicle speakers.




Speed Dial


Speed dial entries and accompanying voice tags* can be stored for quick voice-activated dialing.

Use the audio selector knob to make and enter selections.


1. **Press** the Pick-Up button to go to the Phone screen.
3. **Scroll** through the list to find the entry you want to call, and **select** it.



2. **Select** Speed Dial.



4. The call is connected and heard through the vehicle speakers.



*When a voice tag is stored for a speed dial entry, you can make a call using voice commands. See your Owner's Manual for instructions.

iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Connecting Devices and Playing Audio Files

1. **Pull out** the USB adapter cable from the center console.
2. **Connect** the USB connector to your iPod dock connector or flash drive.
3. **Press** SOURCE or AUX until iPod or USB mode appears. Audio begins to play.
4. **Press** the (⏮) or (⏭) buttons to change tracks, or use the (⏪) or (⏩) buttons on the steering wheel.



2. Connect the USB connector to your iPod dock connector or flash drive.



3. Press SOURCE or AUX until iPod or USB mode appears. Audio begins to play.




iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

BLUETOOTH® AUDIO

Play stored or streaming audio from your compatible phone through your vehicle's audio system. Visit handsfreelink.honda.com to check if this feature is available on your phone.

Playing Bluetooth Audio Files

1. Make sure your phone is on and paired to HandsFreeLink (see [page 10](#)).
2. Press SOURCE or AUX until Bluetooth Audio mode appears.
3. Press "play" on your phone; sound is redirected to the audio system.
4. Press the (⏮) or (⏭) buttons to change tracks, or use the (⏪) or (⏩) buttons on the steering wheel*.



3. Press "play" on your phone; sound is redirected to the audio system.



Notes:


- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional Bluetooth settings on your phone for playback.



*not supported on all phones

OWNER LINK

Owner Link allows you to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information. Register at www.owners.honda.com to ensure that you continue to enjoy the experience of owning a Honda.



REGISTRATION

Questions about registration?
[Find help here.](#)

After registration, you can always click "My Profile" to edit or update your information.

Verification Required

• * required field
Note: Username and password are case sensitive.

• first name last name

• username • password (min. 6 char.) • confirm password

• email address

• confirm email address

VIN or Hull Identification Number (VIN)

promo :

Please Note: E-mail spam filters may block our e-mails from being delivered. If you have a spam blocker, please set it to accept e-mails from "ownerslink@ebizmail.honda.com".

Where can I find my VIN? Benefits of entering VIN

SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

FUEL RECOMMENDATION

- Only use unleaded gasoline of 87 octane or higher. For Civic Si models, unleaded gasoline of 91 octane or higher is required. For Civic GX models, compressed natural gas (CNG) is required.
- Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emissions control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- "TOP TIER Detergent Gasoline" meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines. In most cases, qualifying gasoline retailers will identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. This helps avoid build-up of deposits in your engine and emission control system. Because the level of detergency and harmful metallic additives (such as MMT) in gasoline vary in the market, Honda endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. For more information, visit www.toptiergas.com.
- For further important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit Owner Link at www.owners.honda.com.